


Confidentiality level class 2:

This document intended for a restricted public only (Official Elinchrom agents, partners, suppliers, manufacturers or outsourcers). Any third party dissemination, distribution, copying or use of these documents, without prior permission, is strictly prohibited.

204.069 Clamping Ring



Please make the following «Lock-unlock» operation when you replace the Clamping Ring 204.069 by a new one.

Lock-unlock operation

1. Install the new Clamping Ring 204.069 on the EL-Profoto Adapter 26345. (Do not lock the Clamping Ring)
2. Mount the EL-Profoto Adapter 26345 on a OCF unit (Elinchrom ONE or Elinchrom THREE).
3. Lock and unlock the clamping ring at least 2 times. (Could be a bit hard the first lock)



Never do this operation without a OCF unit ! There is a huge risk to damage the internal metal ring during the first locking.

